


ETCR[®] SUPER-LARGE CALIBER LEAKAGE CLAMP METER

ETCR 7100
ETCR 7100A

<http://www.etcrc.com>



MANUAL


ETCR Electronic Technology Company

CONTENT

I. Safety Precautions And Procedures	1
1. Preliminary Instructions	2
2. During Use	2
3. After Use	3
II. Introduction	3
III. Model	4
IV. Electrical Symbols	4
V. Technical Specification	4
VI. Instrument Structure	6
VII. LCD Display	7
VIII. Method of Operation	7
1. Switch On/Off	7
2. Data Hold/Storage	7
3. Data Access/ Exit	8
4. Data Upload	8
5. Delete Data	8
6. General Measurement	8
7. PEAK Measurement	10
IX. Battery Replacement	10
XI. Accessories	11

I. Safety Precautions And Procedures

This instrument was designed in compliance with IEC1010-1& IEC1010-2-032 safety guideline relative to electronic equipment.

For your own safety and to avoid damaging the instrument you are recommended to follow the procedures described in this manual and read carefully all instructions preceded by this symbol 

Before and during measurements keep to the following instructions:

- Do not take current measurements in wet places
- Do not take the measurements in the presence of explosive gas and combustibles or in dusty places
- Avoid any contact with the circuit under test even though you are not taking any measurement
- Avoid any contact with exposed metal parts, unused measuring terminals, circuits etc. Do not take any measurement whenever anomalous conditions occur such as deformations, breaks, leakages, blind display etc

The herewith symbols are used in this manual and on the meter



CAUTION: refer to the instruction manual. An improper use may damage the instrument or its components as well as endanger the user.




High voltage danger: risk of electric shock

1. Preliminary Instructions

- This instrument has been designed for use in environments with pollution degree 2
- It can be used for voltage and current measurements on electrical installations with overvoltage CAT III 600V
- You are recommended to respect the usual safety regulations aimed at protecting you against dangerous current and protecting the instrument against improper use
- Only the original accessories supplied along with the instrument guarantee compliance with the safety standards in force. They must be in a good condition and, if necessary, replaced with identical ones
- Do not test nor connect to any circuit exceeding the specified overload protection
- Do not take measurements under environmental conditions exceeding the limits indicated in this manual
- Make sure that batteries are correctly installed

2. During Use


You are recommended to read carefully the following instructions:

	CAUTION
Failure to comply with warnings and instructions may damage the instrument and/or its components as well as injure the operator	

- Do not measure in the presence of external voltages. Although the instrument is protected, an excessive voltage may cause malfunction
- Avoid submitting the instrument to voltage while measuring (i.e. a test lead slipping off the measuring point accidentally touching an energized point)



CAUTION



If the “low battery” symbol is displayed during use interrupt testing, switch off the instrument and replace batteries.

⚠(Take note of the polarity when replace the battery.)

3. After Use

- Turn off the instrument pressing ON/OFF key after using it
- If you expect not to use the instrument for a long time remove batteries

II. Introduction

ETCR7100 series of **Super-large Caliber Leakage Clamp Meter** is well designed and manufactured for measuring AC leakage current, current, voltage, adopt the latest CT technology and digital integrated technology. Its large caliber 108mm×148mm can clamp electric cable of 108mm diameter, or 160mm×4mm flat cable and steel earth wires. It is suitable for leakage current measurement of cable and transformer earth steel. Full automatically and LCD display, all the data are displayed in the screen, which is very clear and convenient. The meter is widely used in electric power, communication, meteorology, railway, oil field, architecture, measuring, teaching research unit, industrial mining enterprises, etc.







ETCR7100 series of **Super-large Caliber Leakage Clamp Meter**'s clamp core is made of special alloy, adopt the latest magnetic shielding techniques, to ensure the high precision, high stability and high reliability of perennial uninterrupted measurement. The meter can store 99 sets of data, with RS232 interface, upload stored data to the computer through the system software, implementing online real-time monitoring, historical inquires,

dynamic display. With the function of historical data read, preserve, print, and backlight, data hold, etc. It is a necessary tool for electrical safety testing.

III. Model


Model	Range (AC)	Resolution	Note
ETCR 7100	0.0mA- 3200A	0.1mA	Measure leakage current
ETCR 7100A	0.0A- 4000A	0.1A	Measure big current

IV. Electrical Symbols

	Extremely dangerous! The operator must strictly abide by the safety rules; otherwise there is risk of electric shock, resulting in bodily injury or fatalities.
	Dangerous! The operator must strictly abide by safety rules; otherwise there is risk of electric shock, resulting in bodily injury or fatalities.
	Warning! Safety rules must be strictly abided by, otherwise personal injury or equipment damage may be caused.
	Alternate Current (AC)
	Direct Current (DC)
	Double Insulation

V. Technical Specification


Function	Measure AC leakage current, big current (particularly suitable for leakage current measurement of cable and transformer earth steel)
Power	6V DC(LR6×4 alkaline dry batteries, continuously working for 12 hours)
Test Mode	Clamp CT, integral mode
Clamp Size	108mm×148mm (can clamp electric cable of 108mm diameter, or 160mm×4mm flat cable and steel earth wires)
Measurement Range(AC)	ETCR7100: 0.0mA~3200A ETCR7100A: 0.A~4000A
Resolution(AC)	ETCR7100: 0.1mA

	ETCR7100A: 0.1A
Measurement Accuracy(AC) (23°C±3°C, below 70%RH, measured wire at the center of the clamp)	0.0mA~499A ±2%±5dgt
	500A~999A ±3%±5dgt
	1000A~2999A ±4%±5dgt
	3000A~4000A ±5%±5dgt
Measured Wire Position	Measured wire at approximately the geometric center of the clamp
Data Storage	99 sets, “ FULL ” symbol indicate the memory is full
RS232 Interface	With RS232 interface, download data to computer for analysis and management
Communication Wire	RS232 communication wire, 1.8m
Frequency	50Hz ,60Hz automatic identification
Gear Shift	Automatic shift
Sample Rate	About 2 times/second
Line Voltage	Below AC 600V line measurement
Display Mode	4 digital LCD display, length 47mm×width 28.5mm
Meter Size	Length 350mm × Width 180mm × Height 55mm
Backlight	Suitable for dim places
Data Hold	“ HOLD ” symbol appears
Overflow	“ OL ” symbol appears
Automatic Shutdown	Automatically shutdown about 5 minutes after power on to reduce battery consumption
Voltage Detection	Low battery symbol “  ” appears to remind the replacement of battery when the battery voltage drops below 5.2V.
Weight of Meter	1.5kg (with batteries)
Weight of Package	3kg (with accessories)
Working Temperature and Humidity	-10°C ~ 40°C; 80%rh
Storage Temperature and Humidity	-10°C ~ 60°C; below 70%rh
Insulation	AC 2kV/rms(between core and shell)

strength	
Safety Specifications	IEC1010-1, IEC1010-2-032, 2 class of pollution, CAT III 600V


VI. Instrument Structure

1. Clamp (108mm×148mm)
2. Lock switch (after lock, the clamp can't be open)
3. **HOLD** key 4. **PEAK** key
5. LCD display 6. RS232 interface
7. Opening lever 8. **POWER** key
9. Battery cover 10. Battery cover screw (1 piece)
11. Up and down cover connecting screws (6 pieces)



VII. LCD Display

- (1). PEAK measurement mode symbol
- (2). Symbol of low battery & voltage (display when below 4.8V)
- (3). Symbol of data storage
- (4). Symbol of data access
- (5). 2-digit No. of data storage unit
- (6). Current unit (mA or A)
- (7). Data lock symbol
- (8). Metrication decimal point
- (9). 4-digit LCD figures display
- (10). Symbol of AC



VIII. Method of Operation

1. Switch On/Off

Press **POWER** key to switch on, LCD display, in test mode, press **POWER** key to switch off. The meter will automatically power off after booting 5 minutes later. If LCD display is darker, maybe the battery voltage is too low, please replace batteries.

In data hold mode, firstly press **HOLD** key to cancel the lock, then press **POWER** key to switch off.

2. Data Hold/Storage

In test mode, press **HOLD** key to lock currently displayed value and display "**HOLD**" symbol. At the same time, this locked value as a set of data followed by auto-ID and store, and "**MEM**" symbol flash one time. The meter can store 99 sets of data. If the memory is full, display "**FULL**" symbol.

3. Data Access/ Exit

In test mode, press **PEAK** and **POWER** key to access data inquiry form group “R: 01”, and display “MR” symbol. Press **PEAK** or **POWER** key to increase or decrease the page number, it will automatically return back to group 01 when access the last group.

Press **HOLD** key to exit date inquiry, back to test mode.

4. Data Upload



Connecting the meter and computer with USB-RS232 communication line attached in package. Start up the meter, run software, choose history access, then read, save, report, print history data, etc. The more data storage, take the longer time to read it. Historical data can be saved in Txt text or Excel format.


5. Delete Data


In the date inquiry mode, press **PEAK** and **POWER** key to delete all the stored data, and return back to test mode. At the same time, “dEL” symbol display.

6. General Measurement


During the measurement, the LCD real-time display the value of measured current and leakage current, the value displayed on LCD change with different current and leakage current. No measured value reserved when take the meter away from measured wires, LCD display zero.

	High voltage, very dangerous! Only qualified personnel after training could conduct operation on it. The operator should obey safety regulations; Otherwise there will be the danger of electric shock resulting in personal injury or casualty.
	Dangerous! Can not be used to test voltage higher than 600V. Otherwise there will be the danger of electric shock resulting in personal injury or casualty.

	Make sure the clamp well closed when measuring leakage current and current.
	Make sure the measured wire at approximately the geometric center of the clamp.
	Clean the clamp after finishing measurement, regularly maintain the meter.

	Clamp live wire and null line together to measure leakage current of electric equipment. (Note: 2 wires)
	Clamp earth wire to measure grounding line leakage current of electric equipment. (Note: single wire)
	Clamp four wires of there phase to measure the total leakage current. (Note: 4 wires)
	Clamp main line to measure total current of that main line. (Note: single wire)


Test reference illustrations:




In **HOLD** mode, press **HOLD** key to return back test mode. In data access mode, press **HOLD** key to exit data access, return back to test mode. In **PEAK** mode, press **PEAK** key to exit **PEAK** mode, return back to test mode. After deleting data, it will automatically return back to test mode.


7. PEAK Measurement

The maximum current measurement, during measurement, the meter can automatically compare the changed current, and keep the maximum one. When take the meter away from the measured wire, the measured value can also be kept, so this mode is suitable for the measurement in places where is not easily to read the value displayed on LCD.

In general test mode, press **PEAK** key to access or exit **PEAK** test mode. “” symbol displays in **PEAK** measurement mode. In other mode, should first exit and return back to test mode, and then operate **PEAK** measurement as above steps.

IX. Battery Replacement


	Warning! Make sure the battery cover is well closed before measurement, otherwise there will be danger.
	Take note of the battery polarity, otherwise it may cause damage to the instrument.
	If the battery power is not enough, please change in time.
	Take out the batteries if you expect not to use the meter for a long time.

1. “” is displayed when the power voltage is lower than 5.2V, indicating that the battery should be replaced.
2. Press **POWER** key, make sure the meter is power off. Loosen the battery cover screw, open the plate, replace new batteries and cover the plate, then tighten screw.

3. Press **POWER** key to check whether the batteries are successfully replaced, repeat step 2 if it doesn't work.

XI. Accessories

Main Unit	1 piece
Meter Box	1 piece
RS232 Data Line	1 piece
Disk	1 piece
Battery	4 pieces (Alkaline Dry Battery LR6)
User Manual	1 piece
Guarantee Card	1 piece
Certification	1 piece

 **Manufactured by**

ETCR Electronic Technology Company

Address: F-3F, No.4 Pengshang Zhifu Road, Jiahe, Baiyun District, Guangzhou, Guangdong, China

Post Code: 510440

Tel: (86-20)62199556 62199554

Fax: (86-20)62199550

E-mail: info@etcr.cc

Website: www.etcr.cc