


# EASILY RELEASE YOUR SYSTEM PRESSURE



**CLICK...  
PUMP...  
DONE!**

## SCHEMATIC in (mm)



## DESCRIPTION

The White Hydraulics Release Pump (RP) is a device designed to replace existing, costly and complicated hydraulic brake release hand pumps that are present on various types of mobile equipment. The RP is typically used to release various types of spring applied/hydraulically released brakes. Depending on the brake, typically 1-5 pumps of the RP will release the brake. This enables equipment to be moved to a service area or a recharge/refuel station.

To operate the RP, the equipment operator must depress the valve rod until it is firmly seated. The operator must then pump the pump rod until the brakes are released. If the hydraulic circuit is pressurized at any time during or after the RP has released the brakes, the valve rod will automatically pop out and the mobile equipment will revert to its normal operation. This serves as a built in safety feature that ensures the equipment's normal braking operation is never accidentally disabled.

The RP is a simplified product compared to competitive brands that are currently available. In addition, the product is a cost competitive alternative that offers superior performance and design flexibility.

## ORDER CODES

960020A10AAAA  
960020A11AAAA

Release Pump/without fittings

Release Pump/with -4 JIC fittings installed

苏州帕凯德自动化有限公司

White Hydraulics, Inc  
P.O. Box 1127  
Hopkinsville, KY 42241  
Phone: 1.270.885.1110  
info@whitehydraulics.com

White Hydraulics GmbH  
Christinenstrasse 4  
D-40880 Ratingen Germany  
Phone: 49.2102.123777.0  
contactgmbh@whitehydraulics.com

White Hydraulics, Inc.  
Asian Distribution Center  
Unit 18, 9/F Corporation Park  
11 on Lai Street, Siu Lek Yuen  
Shatin, N.T. Hong Kong  
Phone: 852.2637.6682  
contactchina@whitehydraulics.com