

# Model: BPA-RS600-120 Single Output 600W

The BPA-RS600-120 is a highly reliable, compact, 600W, AC to DC, single output, redundant / removable power supply module. With a full range input of 90-264VAC, this power supply module achieves the highest performance and efficiency by incorporating digital control interleaved PFC and phase-shift full bridge technology. The BPA-RS600 family also includes PMBus<sup>TM</sup> interface to monitor and control all essential functions of the power supply module.

Custom controls available.



| Total<br>Power | Input<br>Voltage | Output<br>Voltage | Minimum | Maximum |
|----------------|------------------|-------------------|---------|---------|
| 600 W          | 90-264           | 12V               | 0A      | 50A     |
|                | VAC              | 12VSB             | 0A      | 1.5A    |

#### Additional Output Configurations Available 12-56VDC

### Special Features

- Compact Size of 50.5 x 40.2 x 245.0 mm
- High efficiency up to 92.0%
- Active Power Factor Correction
- ➤ Wide input voltage range: 90 264VAC
- Redundant operation
- Hot insertion/removal (hot plug)
- Digital Single wire current sharing
   I<sup>2</sup>C interface PMBus<sup>TM</sup> compatible for control, programming and monitoring
- Remote firmware upgrade capable
- Full digital control
- Optional fan airflow direction
- Variable fan speed control
- Series and Parallel Wiring Possible
- Fully secure(OTP, OVP, OCP, SCP)
- ➤ LEDs Status :OK, Fault, Warning
- AC OK, DC OK, PS ON, Alert
- CE Compliant
- RoHS Compliant
- Three Year Warranty
- Approved to latest edition of the following Safety Standards: UL/cUL, and DEMKO
- (To be submitted)
- Custom modifications available

## **Applications**

- High Performance Servers
- Routers
- Switches (POE)
- Telecommunication
- Industrial Application
- > SSD High performance RAID products
- High Speed PCIe super computers
- > Thunderbolt applications



Phone: 973-594-1800 Salesteam@BluTekPower.com


© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

## 1. Input Specifications

| Parame             | ter                    | Description/Condition   | Min | Nom   | Max | Units            |
|--------------------|------------------------|---|-----|-------|-----|------------------|
| V <sub>i nom</sub> | Nominal Input Voltage  |   | 100 |       | 240 | VAC              |
| Vi                 | Input Voltage Ranges   | Normal operating ( $V_{min}$ to $V_{max}$ )                       | 90  |       | 264 | VAC              |
| I <sub>i max</sub> | Max. Input Current     | V <sub>in</sub> =90VAC/60HZ,Full Load                             |     |       | 8.7 | A <sub>rms</sub> |
| l <sub>i p</sub>   | Inrush Current         | 264V <sub>rms</sub> ,25°C   |     |       | 32  | $A_p$            |
|                    | Leakage Current        |   |     |       | 0.8 | mA               |
| Fi                 | Input Frequency        |   | 47  | 50/60 | 63  | Hz               |
| PF                 | Power Factor           | V <sub>in</sub> =230V/50Hz  |     | 0.95  |     | W/VA             |
| V <sub>i on</sub>  | Turn-on Voltage        | Ramping Up  | 87  |       | 89  | VAC              |
| V <sub>i off</sub> | Turn-off Voltage       | Ramping Down  | 72  |       | 83  | VAC              |
| Poweri             | Input Power            | V <sub>in</sub> = 90VAC-264VAC                                    |     |       | 750 | W                |
|                    |                        | V <sub>in</sub> =230V, 12V /10A, 12V /0.3A ,T <sub>A</sub> =25°C  |     | 88    |     |                  |
| η                  | Efficiency without Fan | V <sub>in</sub> =230V, 12V /25A, 12V /0.75A ,T <sub>A</sub> =25°C |     | 92    |     | %                |
|                    |                        | V <sub>in</sub> =230V, 12V /50A, 12V /1.5A ,T <sub>A</sub> =25°C  |     | 91    |     |                  |
| T <sub>hold</sub>  | Hold-up Time           |   | 16  |       |     | ms               |

- 1.1 Input Fuse An internal 10A input fuse, in series with the input line, protects against severe defects.
- **1.2 Inrush Current** When the power supply module is connected to the main input, it exhibits a low and short peak current due to an X-capacitances initial charge. The internal bulk capacitor is charged through a controlled NTC circuit which will limit the inrush current.
- **1.3 Input Under-Voltage** If the input voltage stays below the specified input voltage range for more than 10 seconds the main output will shut down. The power supply module will automatically return to normal operational condition when the input voltage returns to the specified range.
- **1.4 Power Factor Correction** Power factor correction (PFC) is achieved by controlling the input current waveform synchronous with the input voltage. A fully digital controller is implemented giving outstanding PFC results over wide input voltage and load ranges.



Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc

# 2. Output Specifications

| Parame                | ter                      | Description/Condition   | Min   | Nom   | Max   | Units     |
|-----------------------|--------------------------|---|-------|-------|-------|-----------|
| Main Oเ               | ıtput V₁                 |   |       |       |       |           |
| $V_{1 \text{ nom}}$   | Nominal Output Voltage   | $0.5 *I_{nom},T_{amb} = 25 °C$  |       | 12.02 |       | VDC       |
| V <sub>1 set</sub>    | Output Setpoint Accuracy | 0.5 *I <sub>nom</sub> ,T <sub>amb</sub> =25°C   | -0.04 |       | 0.04  | $V_1$     |
| P <sub>1 nom</sub>    | Nominal Output Power     | V <sub>1</sub> =12 VDC  |       | 600   |       | W         |
| I <sub>1 nom</sub>    | Nominal Output Current   | V <sub>1</sub> =12 VDC  |       | 50    |       | $A_{DC}$  |
| V <sub>1 pp</sub>     | Output Ripple Voltage    | V <sub>1 nom</sub> , I <sub>1 nom</sub> ,20MHz BW                                     |       |       | 120   | $mV_{pp}$ |
| $dV_{1Load}$          | Load Regulation          | $V_i = V_{i \text{ nom}}, 0 - 100\% I_{1 \text{ nom}}$                                | -1    |       | 1     | %V        |
| dV <sub>1 Line</sub>  | Line Regulation          | $V_i = V_{i \text{ min}} \dots V_{i \text{ max}}$                                     | -0.2  |       | 0.2   | %V        |
| $dV_{1 tot}$          | Total Regulation         | $V_{i  min}$ to $V_{i  max}$ , 0 to 100% $I_{1  nom}$ , $T_{a  min}$ to $T_{a  max}$  | -1    |       | 1     | $%V_{1}$  |
| dl <sub>share</sub>   | Current Sharing          | when Bus load ≥ (20%)   | -5%   |       | 5%    | Α         |
| dl <sub>share</sub>   | Current Sharing          | when Bus load< (20%)  | -10%  |       | 10%   | Α         |
| $dV_{dyn} \\$         | Dynamic Load Regulation  | l <sub>out</sub> :10%60% of full load;50100% of full load                             | -0.3  |       | 0.3   | V         |
| T <sub>rec</sub>      | Recovery Time            | $dI_1/dt = 1A/\mu s$ , recovery within 1% of $V_{1 \text{ nom}}$                      |       | 0.2   | 1     | ms        |
| t <sub>AC V1</sub>    | Start-up Time from AC    | Varies with Input Line  |       |       | 3     | sec       |
| tV <sub>1 rise</sub>  | Rise Time                | V <sub>1</sub> =10%90% V1 <sub>nom</sub>  |       | 100   |       | ms        |
| $C_Load$              | Capacitive Loading       | T <sub>amb</sub> =25°C  |       |       | 30000 | μF        |
| Standby               | Output V <sub>SB</sub>   |   |       |       |       |           |
| $V_{\text{SB nom}}$   | Nominal Output Voltage   | $0.5 \cdot I1_{nom}, T_{amb} = 25^{\circ}C$   |       | 12    |       | VDC       |
| $V_{\text{SB set}}$   | Output Setpoint Accuracy | $0.5 \cdot I1_{\text{nom}}, T_{\text{amb}} = 25^{\circ}C$                             | .3    |       | .3    | $V_{SB}$  |
| P <sub>SB nom</sub>   | Nominal Output Power     | V <sub>SB</sub> = 12VDC   |       | 18    |       | W         |
| I <sub>SB nom</sub>   | Nominal Output Current   | V <sub>SB</sub> = 12VDC   |       | 1.5   |       | $A_{DC}$  |
| $V_{SBpp}$            | Output Ripple Voltage    | V <sub>SB</sub> ,I <sub>SB</sub> , 20MHz BW   |       |       | 120   | $mV_{pp}$ |
| $dV_{SB\ tot}$        | Total Regulation         | $V_{imin}$ to $V_{imax},0$ to 100% $I_{1nom},T_{amin}$ to $T_{amax}$                  | -3    |       | 3     | $%V_{SB}$ |
| $dV_{SB}$             | Droop                    | 0 - 100% I <sub>SB nom</sub>  |       |       | .3    | V         |
| $dV_{SBdyn} \\$       | Dynamic Load Regulation  | $\Delta I_{SB} = 50\%$ , $I_{SB \text{ nom}}$ , $I_{SB}$ 5100% $I_{SB \text{ nom}}$ , | -0.3  |       | 0.3   | $%V_{SB}$ |
| T <sub>rec</sub>      | Recovery Time            | dl <sub>1</sub> /dt =1A/μs,recovery within 1% of V <sub>SB nom</sub>                  |       |       | 1.2   | ms        |
| t <sub>AC VSB</sub>   | Start-up Time from AC    | Varies with Input Line  | 0.2   |       | 1.2   | sec       |
| tV <sub>SB rise</sub> | Rise Time                | V <sub>SB</sub> = 10%90%VSB <sub>nom</sub>  |       | 20    |       | ms        |
| $C_Load$              | Capacitive Load          | T <sub>amb</sub> =25°C  |       |       | 10000 | μF        |

**2.1. Output Voltage Ripple** Ripple and noise are measured with  $0.1\mu F$  of ceramic capacitance and  $10~\mu F$  of tantalum capacitance on each of the outputs.

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

中国区总代理:上海佳舍珀电子科技有限公司

Page 3 of 19

### 3. Protection

| Param                  | eter                                       | Description/Condition                   | Min  | Nom | Max  | Units |
|------------------------|--|---|------|-----|------|-------|
| F <sub>1</sub>         | Input Fuse                                 | Not user accessible                     |      | 10  |      | Α     |
| $V_{1  OV}$            | Overvoltage Threshold V <sub>1</sub>       |   | 13.2 |     | 14.4 | VDC   |
| t <sub>OV V1</sub>     | Overvoltage Latch Off Time V <sub>1</sub>  |   |      |     | 1    | ms    |
| $V_{\text{SB OV}}$     | Overvoltage Threshold V <sub>SB</sub>      |   | 13.2 |     | 14.4 | VDC   |
| t <sub>OV VSB</sub>    | Overvoltage Latch Off Time V <sub>SB</sub> |   |      |     | 1    | ms    |
| I <sub>V1 lim</sub>    | Current Limit                              |   | 52   |     | 55   | Α     |
| V <sub>1 SC Max</sub>  | Short Circuit Current V <sub>1</sub>       | V <sub>1</sub> < 3V                     |      |     | 110  | Α     |
| t <sub>V1 SC off</sub> | Short Circuit Latch Off Time               | Time to latch off when in short circuit |      |     | 30   | ms    |
| $T_{SD}$               | Over Temperature Protection                | Internal temperature                    |      | 115 | 120  | °C    |
|                        | Recovery Temperature                       |   |      | 70  |      | °C    |
| I <sub>VSB lim</sub>   | Standby Current Limit                      | Auto Recovery                           |      |     | 3    | Α     |

- **3.1 Overvoltage Protection** The power supply module will shut down if the output voltage exceeds the overvoltage threshold. The power supply module must be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>TM</sup> operation command.
- **3.2 Undervoltage Protection** The power supply module will shutdown if the output voltage falls below undervoltage threshold (10.8-11.5V). The power supply module must be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>TM</sup> operation command.
- **3.3 Overload Protection\*** Constant current until the undervoltage threshold point (10.8-11.5V). The power supply will turn off when it falls under the undervoltage threshold on the primary output. The 12V standby utilizes the hiccup method. The power supply module must be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>TM</sup> operation command.
- **3.4 Short-circuit Protection\*** Latching method on the main output. The 12V standby utilizes the hiccup method. The power supply module must be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>TM</sup> operation command.
- **3.5 Over Temperature Protection** The power supply module will shut down if temperature exceeds the over temperature threshold (internal temperature). The power supply module will restart when temperature falls below recovery temperature threshold. The power supply module can also be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>TM</sup> operation command.

## 4. Safety/Approval

\*For overload and short circuit protection, when the power supply turns on, and there is excessive load, the power supply will remain in constant current for 2sec before shutting off. This is to allow multiple power supplies to turn on in parallel.

| Parameter                | Description/Condition   | Min  | Nom                          | Max | Units |
|--------------------------|---|------|------------------------------|-----|-------|
| Agency Approvals         | Approved to the latest edition of the following standards: UL/cUL 60950-1 |      | Approved by independent body |     |       |
|                          | IEC/EN 60950-1  |      | independent body             |     |       |
| Isolation Strength       | Input(L/N) to Case (PE)   | 1500 | Basic                        |     | Vrms  |
|                          | Input (L/N) to Output   | 3000 | Reinforced                   |     | Vrms  |
|                          | Output to Case (PE)   | 500  | Functional                   |     | VDC   |
| Electrical Strength Test | Input to Case   | 2121 |                              |     | VDC   |
|                          | Input to Output   | 4242 |                              |     | VDC   |

Phone: 973-594-1800
Salesteam@BluTekPower.com

BPA-RS600-120-Preliminary 07-19-2018

中国区总代理:上海佳舍珀电子科技有限公司

Page 4 of 19

## 5. Electromagnetic Compatibility

### **5.1 Immunity**

| Parameter                         | Description/Condition   | Criterion             |
|-----------------------------------|---|-----------------------|
| ESD Contact Discharge             | IEC/EN61000-4-2, Level 2 ±4kV   | Α                     |
| Radiated Electromagnetic Field    | IEC/EN61000-4-3,Level 2 (3V/m) 80-1000MHz, 1.4-2.0GHz,<br>Level 1 (1V/m) 2.0-2.7GHz   | A<br>A                |
| Electrical Fast Transients/ Burst | IEC/EN61000-4-4,level 2 AC port ±1kV,1 minute   | Α                     |
| Surge                             | IEC/EN61000-4-5,<br>Level 2 AC port± 1kV,1 min CM,<br>Level 3 AC port ±2kV,1 min CM   | A<br>A                |
| RF Conducted Immunity             | IEC/EN 61000-4-6,Level 2, 3 V,CW,0.15 80MHz<br>Amplitude Modulation 1kHz/80%  | А                     |
| Magnetic Field Immunity           | IEC/EN 61000-4-8,Level 2 3A/m   | Α                     |
| Voltage Dips and Interruptions    | IEC/EN61000-4-11 1.0% residual voltage, 0.5 cycle 2.0% residual voltage, 1 cycle 3.40% residual voltage, 5 cycles 4.70% residual voltage, 0.5 cycle 5.70% residual voltage, 25 cycles/50Hz 6.0% residual voltage, 250 cycles/50Hz | A<br>B<br>B<br>A<br>B |

#### **5.2 Emission**

| Parameter           | Description/Condition                          | Criterion |
|---------------------|--|-----------|
| Conducted Emissions | EN 55032 / EN 55016-2-1 conducted              | Class A   |
| Radiated Emission   | EN 55032 / EN 55016-2-3 radiated               | Class A   |
| Harmonics Emission  | IEC61000-3-2,Vin =230VAC/50Hz,100% Load        | Class A   |
| Acoustical Noise    | 46dB at 1 meter, 25 C , 50% Load               | -         |
| AC Flicker          | IEC61000-3-3,Vin=230VAC/50Hz,100% Load,<20Arms | Pass      |

# 6. Environmental Specifications

| Par            | ameter              | Description/Condition                                  | Min | Nom   | Max | Units |
|----------------|---------------------|--|-----|-------|-----|-------|
| T <sub>A</sub> | Ambient Temperature | $V_{i  min} \ to \ V_{i  max, I1  nom, ISB  nom}$      | -20 |       | 70* | °C    |
| Ts             | Storage Temperature | Non- operational                                       | -40 |       | 85  | °C    |
|                | Altitude            | Operational, above Sea Level                           |     | 5000  |     | Meter |
|                |                     |  |     | 16400 |     | Feet  |
| RH             | Humidity            | Non-condensing   | 5   |       | 95  | %     |
| Na             | Audible Noise       | $V_{i \text{ nom}}$ ,50% $I_{o \text{ nom}}$ ,Ta =25°C |     | 42    |     | dBa   |

<sup>\*</sup>Derating linearly from 51° -70°C @ 50% load.

Phone: 973-594-1800 Salesteam@BluTekPower.com

BPA-RS600-120-Preliminary 07-19-2018 © 2017 BluTek Power, Inc

<sup>\*</sup>Below 100VAC Derating linearly 46°-70°C @ 50% load.

## 7. Signals and Controls

#### 7.1 Electrical Characteristics

| Paramete              | r                                    | Min | Nom  | Max  | Unit |
|-----------------------|--------------------------------------|-----|------|------|------|
| PS_ON                 |                                      |     |      |      |      |
| $V_{IL}$              | Input Low Level Voltage              | 0   |      | 0.8  | V    |
| $V_{IH}$              | Input High Level Voltage             | 2.4 |      | 3.3  | V    |
| $R_{puPS\_ON}$        | Internal Pull Up Resistor on PS_ON   |     | 10   |      | kΩ   |
| AC_OK/D               | C_OK/Alert                           |     |      |      |      |
| V <sub>IL</sub>       | Input Low Level Voltage              | 0   |      | 0.8  | V    |
| $V_{IH}$              | Input High Level Voltage             | 2.4 |      | 3.3  | V    |
| $I_{IL,H}$            | Maximum Input Sink or Source Current | 0   |      | 10   | mA   |
| $R_{puAC\_OK}$        | Internal Pull Up Resistor on AC_OK   |     | none |      | kΩ   |
| $R_{\text{puDC\_OK}}$ | Internal Pull Up Resistor on DC_OK   |     | none |      | kΩ   |
| R <sub>puAlert</sub>  | Internal Pull Up Resistor on Alert   |     | none |      | kΩ   |
| SCL_1/SI              |                                      |     |      |      |      |
| $V_{IL}$              | Input Low Level Voltage              | 0   |      | 0.8  | V    |
| $V_{IH}$              | Input High Level Voltage             | 2.4 |      | 3.3  | V    |
| $I_{IL,H}$            | Maximum Input Sink or Source Current |     |      | 0.25 | mA   |
| R <sub>puSCL_1</sub>  | Internal Pull Up Resistor on SCL_1   |     | 3    |      | kΩ   |
| R <sub>puSDA_1</sub>  | Internal Pull Up Resistor on SDA_1   |     | 3    |      | kΩ   |
| A0/A1/A2              |                                      |     |      |      |      |
| V <sub>IL</sub>       | Input Low Level Voltage              | 0   |      | 0.8  | V    |
| $V_{IH}$              | Input High Level Voltage             | 2.4 |      | 3.3  | V    |
| R <sub>puA0</sub>     | Internal Pull Up Resistor on A0      |     | 10   |      | kΩ   |
| R <sub>puA1</sub>     | Internal Pull Up Resistor on A1      |     | 10   |      | kΩ   |
| R <sub>puA2</sub>     | Internal Pull Up Resistor on A2      |     | 10   |      | kΩ   |
| PS_PRE                |                                      |     |      |      |      |
| R <sub>puPS_PRE</sub> | Internal Resistor to COM             |     | 0    |      | Ω    |

- **7.2 PS\_ON** The PS\_ON signal is used to remotely enable/disable the main output V1 of the front-end. This active-low pin is also used to clear any latched fault condition.
- **7.3 PS\_Present** The PS\_Present signal is internally connected to COM. This active-low signal is used to indicate to a power distribution unit controller that the power supply module is fully engaged.
- **7.4 AC\_OK** The AC\_OK is an open collector signal with an active-high when the AC input voltage is above 88VAC and an active-low when the AC voltage falls outside the requirements for more than 10ms.
- **7.5 DC\_OK** The DC\_OK is an open collector signal with an active-high that indicating whether both VSB and V1 outputs are within regulation. This pin is active-low when V1 and VSB are not within regulation.

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power Inc.

BPA-RS600-120-Preliminary 07-19-2018

Page 6 of 19

中国区总代理:上海佳舍珀电子科技有限公司

**7.6 Current Share (12VCS)** When used in a redundant configuration, all the current share pins need to be interconnected in order to activate the sharing function. If a supply has an internal fault or is not turned on, the current share line will automatically disengage from the bus.

If current share is not required the current share pin can be left open.

- **7.7 Remote Sense (+VS and -VS)** The main output incorporates sense lines to compensate for voltage drop across the load line.
  - 1. (+) Sense connects to the positive rail of the equipment used. Maximum voltage drop of 200mV.
  - 2. (-) Sense connects to the negative rail of the equipment used. Maximum voltage drop of 200mV.

If remote sense is not required the (+) Sense and (-) Sense pins can be left open.

**7.8 Alert** Fault/Warning - An open collector signal is provided to indicate any fault or warning such as over temperature, overvoltage, over current, undervoltage, and fan fault.

#### **7.8.1 Front LED**

| Power Supply Condition | Alert State | Green LED | Yellow LED | AC_OK | DC_OK |
|------------------------|-------------|-----------|------------|-------|-------|
| Normal Operation       | High        | On        | Off        | High  | High  |
| Standby Mode           | High        | Blink     | Off        | High  | Low   |
| PSU Faults Condition   |             |           |            |       |       |
| Input Undervoltage     | Low         | Off       | On         | Low   | Low   |
| Output Overvoltage     | Low         | Off       | On         | High  | Low   |
| Fan                    | Low         | Off       | On         | High  | Low   |
| Over Temperature       | Low         | Off       | On         | High  | Low   |
| Output Over Current    | Low         | Off       | On         | High  | Low   |
| PSU Warning Condition  |             |           |            |       |       |
| Over Temperature       | Low         | On        | Blink      | High  | High  |
| Fan Speed(Low Speed)   | Low         | On        | Blink      | High  | High  |
| Output Over Current    | Low         | On        | Blink      | High  | High  |
| Input Undervoltage     | Low         | On        | Blink      | Low   | High  |

See Page 4 (3. Protections) for fault Threshold.
For Faults the power supply module must be manually repowered by recycling AC Source, by toggle PS\_ON, or PMBus<sup>™</sup> operation command.


### 7.8.2 Warnings

| PSU Warning Triggers | Min  | Nom  | Max  | Units |
|----------------------|------|------|------|-------|
| Over Temperature     |      | 115  |      | °C    |
| Fan Speed(Low RPM)   | 2400 | 2500 | 2600 | RPM   |
| Output Over Current  |      | 52   |      | Α     |
| Input Undervoltage   |      | 85   |      | VAC   |

Phone: 973-594-1800 Salesteam@BluTekPower.com

BPA-RS600-120-Preliminary 07-19-2018 © 2017 BluTek Power, Inc

**7.9 SDA &SCL** The I2C bus consist of a Serial Clock (SCL) and a Serial Data Line (SDA). Both signals lines are pull up internally to 3.3V bus via 6.8k ohm resistors, if customer requires stronger pull up resistors, it is possible to install additional pull up resistors in the customer's backplane.




**7.10 Address Select (A0, A1, A2)** These digital input lines are used to set the address of the power supply module. These addresses are used to differentiate between multiple power supply modules utilize in a redundant mode within the same system.

### 7.11 PSU Address Table (Address Bit Settings)

| A0, A1, & A2 | PSU Address Value | A2 | A1 | A0 | Recognize Address |
|--------------|-------------------|----|----|----|-------------------|
| 00h          | B0h               | 0  | 0  | 0  | Yes               |
| 01h          | B2h               | 0  | 0  | 1  | Yes               |
| 02h          | B4h               | 0  | 1  | 0  | Yes               |
| 03h          | B6h               | 0  | 1  | 1  | Yes               |
| 04h          | B8h               | 1  | 0  | 0  | Yes               |
| 05h          | BAh               | 1  | 0  | 1  | Yes               |
| 06h          | BCh               | 1  | 1  | 0  | Yes               |
| 07h          | BEh               | 1  | 1  | 1  | Yes               |

Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc

### 7.12 Timing Graph



| Parameter             |                          | Description/Condition                      | Min  | Nom    | Max  | Unit |
|-----------------------|--------------------------|--|------|--------|------|------|
| t <sub>risetime</sub> | 12VOUT,0V to 12V         | 2000.194017,0011414011                     | 80   | 100    | 120  | ms   |
| V <sub>Htrigger</sub> | DCOK(high)               | Varies due to Load                         | 11.5 | -      | 11.8 | V    |
| V <sub>Ltrigger</sub> | DCOK(low)                | Varies due to Load                         | 10.8 | 11.2   | 11.5 | V    |
| Turn-On               |                          |  |      |        |      |      |
| t <sub>1</sub>        | AC INPUT - VSB           | Varies due to Line and Load                | 200  | Varies | 1200 | ms   |
| $t_2$                 | VSB - AC_OK              |  | -    | 230    | 300  | ms   |
| $t_3$                 | AC_OK - 12VOUT           | Varies due to Line and Load                | .4   |        | 1    | S    |
| $t_4$                 | 12VOUT - DC_OK           |  | 120  | -      | 200  | ms   |
| t <sub>8</sub>        | PS_ON(low) - 12VOUT      | PS_ON Turn-On                              | .8   | -      | 1.5  | S    |
| Turn-Off              |                          |  |      |        |      |      |
| t <sub>5</sub>        | AC INPUT - AC_OK         | AC IN Turn-Off                             | 10   | -      | -    | ms   |
| t <sub>6</sub>        | AC_OK - DC_OK            | AC IN Turn-Off<br>Varies due to Load       | 7    | -      | -    | ms   |
| t <sub>7</sub>        | DC_OK - VSB              | AC IN Turn-Off Varies due to Line and Load | 180  | -      | -    | ms   |
| $t_9$                 | DC_OK - 12VOUT           | PS_ON Turn-Off                             | 400  | 440    | 480  | μs   |
| t <sub>10</sub>       | PS_ON(high) - DC_OK(low) | PS_ON Turn-Off                             | -    | 10     | -    | ms   |

Phone: 973-594-1800 Salesteam@BluTekPower.com

BPA-RS600-120-Preliminary 07-19-2018

Page 9 of 19

© 2017 BluTek Power, Inc

# 7.13 PMBus<sup>™</sup> Functionality Supported By PSU (PMBus<sup>™</sup> Info)

| Address | Commands         | Description  | Supported | Transaction-<br>Type | Byte_Size |
|---------|------------------|--|-----------|----------------------|-----------|
| 01h     | Operation_ON_OFF | Used to enable or disable the output of the PSU depending value of the second byte that follows.   | Y         | Read/Write           | 2-bytes   |
| 03h     | Clear_Fault      | Used to clear all status registers and error flags. This command also affects the SMB_ALERT signal.  | Y         | Write Only           | 1-byte    |
| 19h     | Capability       | Used by the end user system to query the PSU, to determine if it supports certain features, or not. Features such packet error checking, SMB_ALERT and the max SMBUS clock rate.   | Y         | Read Only            | 1-byte    |
| 20h     | VOUT_Mode        | Sets/reads the formats (Linear, VID, and Direct) and exponents for VOUT related commands.  | Y         | Read Only            | 1-byte    |
| 3Bh     | Fan_Command_1    | Used by the end user system to override the fan speed versus temperature algorithm of the PSU, so that the system can set the fan speed to where ever it requires within the limits of the fan specification.                        | Y         | Read/Write           | 2-bytes   |
| 78h     | Status_Byte      | Used to retrieve and report one byte containing a summary of the most critical faults. All bits in this register should read as zero when the PSU is operating normally.   | Y         | Read/Write           | 1-byte    |
| 79h     | Status_Word      | Used to retrieve and report two bytes containing a summary of faults conditions. All bits in this register should read as zero when the PSU is operating normally. This register acts as on index to all the other status registers. | Y         | Read/Write           | 2-bytes   |
| 7Ah     | Status_VOUT      | Used to retrieve and report the status of the output voltages. It reports information such as output undervoltage, output over-voltage, output under voltage-warning   | Y         | Read/Write           | 1-byte    |
| 7Bh     | Status_IOUT      | Used to retrieve and report the status of the device output current. It relays information, such as output over current conditions, exceeded and output current approaching it maximum rating.                                       | Y         | Read/Write           | 1-byte    |
| 7Ch     | Status_INPUT     | Used to retrieve and report the status of the device input. It relays information, such as input over current, input over power, input OVP rating exceeded and input current approaching it maximum rating.                          | Y         | Read/Write           | 1-byte    |

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

Page 10 of 19

# 7.13 PMBus<sup>™</sup> Functionality Supported By PSU (PMBus<sup>™</sup> Info) - Continued

| Address | Commands           | Description  | Supported | Transaction-<br>Type | Byte_Size |
|---------|--------------------|--|-----------|----------------------|-----------|
| 7Dh     | Status_Temperature | Used to retrieve and report the status of the device operating temperatures both ambient and heat-sinks.   | Y         | Read/Write           | 1-byte    |
| 7Eh     | Status_CML         | Used to retrieve and report the status of the I2C or SMBUS communication bus; error such as packet error checking (PEC), receive an unsupported command etc  | <b>Y</b>  | Read/Write           | 1-byte    |
| 81h     | Status_Fans_1&2    | Used to retrieve and report the operating status of fan_1 & 2.   | Y         | Read/Write           | 1-byte    |
| 88h     | Read_VIN           | Used to retrieve a two bytes value in Little Endian format representing the active input voltage of the device in a linear format (VIN = Y*2 <sup>-2</sup> ), where n is the exponent in two's compliment represented by the five most significant bits of the upper byte. Y is the mantissa represented the eleven lower bits of the two byte word. | Y         | Read Only            | 2-bytes   |
| 89h     | Read_IIN           | Used to retrieve a two bytes value in Little Endian format representing the active input current of the device in a linear format (IIN = Y*2 <sup>-5</sup> ), where n is the exponent in two's compliment represented by the five most significant bits of the upper byte. Y is the mantissa represented the eleven lower bits of the two byte word. | Y         | Read Only            | 2-bytes   |
| 97h     | Read_PIN           | Used to retrieve a two bytes value in Little Endian format representing the active input power of the device in a linear format (PIN = Y*2 <sup>1</sup> ), where n is the exponent in two's compliment represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word. | Y         | Read Only            | 2-bytes   |
| 8Bh     | Read_VOUT          | Used to retrieve a two bytes value in Little Endian format representing the active output voltage of the device in a linear format (VOUT = Y*2-9), VOUT is a special case where the mantissa and the exponent are not combined, but listed separately.   | Y         | Read Only            | 2-bytes   |
| D1h     | Standby_VOUT       | Used to retrieve a two bytes value in Little Endian format representing the standy output voltage of the device in a linear format (Standby_VOUT = Y*2 <sup>-9</sup> ), VOUT is a special case where the mantissa and the exponent are not combined, but listed separately.  | Y         | Read Only            | 2-bytes   |

Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

Page 11 of 19

# 7.13 PMBus<sup>™</sup> Functionality Supported By PSU (PMBus<sup>™</sup> Info) - Continued

| Address | Commands                     | Description   | Supported | Transaction-<br>Type | Byte_Size                     |
|---------|------------------------------|---|-----------|----------------------|-------------------------------|
| 8Ch     | Read_IOUT                    | Used to retrieve a two bytes value in Little Endian format representing the active output current of the device in a linear format (IOUT = Y*2 <sup>-4</sup> ), where n is the exponent in two's compliment represented by the five most significant bits of the upper byte. Y is the mantissa represented the eleven lower bits of the two byte word.          | Y         | Read Only            | 2-bytes                       |
| D0h     | Standby_IOUT                 | Used to retrieve a two bytes value in Little Endian format representing the standby output current of the device in a linear format (Standby_IOUT = Y*2 <sup>-5</sup> ), where n is the exponent in two's compliment represented by the five most significant bits of the upper byte. Y is the mantissa represented the eleven lower bits of the two byte word. | Y         | Read Only            | 2-bytes                       |
| 96h     | Read_POUT                    | Used to retrieve a two bytes value in Little Endian format representing the active output power of the device in a linear format (POUT = Y*2 <sup>1</sup> ), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word.  | Y         | Read Only            | 2-bytes                       |
| D5h     | StandBy_POUT                 | Used to retrieve a two bytes value in Little Endian format representing the standby output power of the device in a linear format (StandBy_POUT = Y*2²), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word.      | Y         | Read Only            | 2-bytes                       |
| 98h     | PMBus <sup>™</sup> _Revision | Used to set and retrieve the version of the PMBus <sup>TM</sup> specification, with which the PSU is in compliance.   | Y         | Read Only            | 1-byte                        |
| 9Ah     | MFR_Model                    | Used to set and retrieve the manufacturer's model number assign to the device.  | Y         | Read/Write           | Variable plus<br>1-byte count |
| 9Bh     | MFR_Revision                 | Used to set and retrieve the manufacturer's revision of the device.   | Y         | Read/Write           | 1-byte                        |
| 9Ch     | MFR_Location                 | Used to set and retrieve the location of manufacturing of the device.   | Y         | Read/Write           | Variable plus<br>1-byte count |
| 9Dh     | MFR_Date                     | Used to set and retrieve the date of manufacturing of the device.   | Y         | Read/Write           | 4-bytes plus<br>1byte count   |

Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

Page 12 of 19

| Address | Commands         | Description  | Supported | Transaction-<br>Type | Byte_Size                        |
|---------|------------------|--|-----------|----------------------|----------------------------------|
| 9Eh     | MFR_Serial       | Used to set and retrieve the value of the manufacturer's serial number assigned to the device.   | Y         | Read/Write           | Variable<br>plus 1-byte<br>count |
| A0h     | MFR_VIN_MIN      | Used to retrieve the value of the minimum rated input voltage, that the PSU can be operated. Also, utilizes the Little Endian format where the two's compliment exponent is (VIN _ MIN= Y*2 <sup>1</sup> ).                  | Y         | Read Only            | 2-bytes                          |
| A1h     | MFR_VIN_MAX      | Used to retrieve the value of the maximum rated input voltage, that the PSU can be operated safely. Also, utilizes the Little Endian format where the two's compliment exponent is (VIN _ MAX= Y*2 <sup>1</sup> ).           | Y         | Read Only            | 2-bytes                          |
| A2h     | MFR_IIN_MAX      | Used to retrieve the value of the maximum rated input current in Amps, that the PSU can be operated. Also, utilizes the Little Endian format where the two's compliment exponent is (IIN _ MAX= Y*2 <sup>6</sup> ).          | Y         | Read Only            | 2-bytes                          |
| A3h     | MFR_PIN_MAX      | Used to retrieve the value of the maximum rated output power in Watts, that the PSU can be operated. Also, utilizes the Little Endian format where the two's compliment exponent is (PIN _ MAX= Y*2 <sup>1</sup> ).          | Y         | Read Only            | 2-bytes                          |
| A4h     | MFR_VOUT_MIN     | Used to retrieve the value of the minimum rated output voltage that the PSU can provide. Also utilizes the Little Endian format where the two's compliment exponent is (VOUT _ MIN= Y*2 <sup>-9</sup> ).                     | Y         | Read Only            | 2-bytes                          |
| A5h     | MFR_VOUT_MAX     | Used to retrieve the value of the maximum rated output voltage that the PSU can provide. Also utilizes the Little Endian format where the two's compliment exponent is (VOUT _ MAX= Y*2-9).                                  | Y         | Read Only            | 2-bytes                          |
| A6h     | MFR_IOUT_MAX     | Used to retrieve the value of the maximum rated output current in Amps, that the PSU is expected to provide. Also, utilizes the Little Endian format where the two's compliment exponent is (IOUT_ MAX= Y*2 <sup>-4</sup> ). | Y         | Read Only            | 2-bytes                          |
| A7h     | MFR_POUT_MAX     | Used to retrieve the value of the maximum rated output power in Watts, that the PSU is expected provide. Also, utilizes the Little Endian format where the two's compliment exponent is (POUT _ MAX= Y*2 <sup>1</sup> ).     | Y         | Read Only            | 2-bytes                          |
| A8h     | MFR_TAMBIENT_MAX | Used to retrieve the value of the maximum ambient temperature that the PSU can be operated, in degree Celsius. Also, utilizes the Little Endian format where the two's compliment exponent is $(TAMBIENT\_MAX = Y*2^2)$ .    | Y         | Read Only            | 2-bytes                          |
| A9h     | MFR_TAMBIENT_MIN | Used to retrieve the value of the minimum ambient temperature that the PSU can be operated, in degree Celsius. Also, utilizes the Little Endian format where the two's compliment exponent is (TAMBIENT_MIN= Y*2²).          | Y         | Read Only            | 2-bytes                          |

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power, Inc

# 7.13 PMBus<sup>™</sup> Functionality Supported By PSU (PMBus<sup>™</sup> Info) - Continued

| Address | Commands           | Description  | Supported | Transaction-<br>Type | Byte_Size |
|---------|--------------------|--|-----------|----------------------|-----------|
| 8Dh     | Read_Temperature_1 | Used to retrieve a two bytes value in Little Endian format representing the ambient temperature of the device in a linear format (Temp_1 = Y*2²), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word. Reads the ambient temperature around the input connector.  | Y         | Read Only            | 2-bytes   |
| 8Eh     | Read_Temperature_2 | Used to retrieve a two bytes value in Little Endian format representing the ambient temperature of the device in a linear format (Temp_2 = Y*2²), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word. Reads the ambient temperature around the output connector. | Y         | Read Only            | 2-bytes   |
| DAh     | Read_Temperature_3 | Used to retrieve a two bytes value in Little Endian format representing the component temperature of the device in a linear format (Temp_3 = Y*2²), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word. Reads the temperature of PFC FETS.                       | Y         | Read Only            | 2-bytes   |
| DBh     | Read_Temperature_4 | Used to retrieve a two bytes value in Little Endian format representing the component temperature of the device in a linear format (Temp_3 = Y*2²), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word. Reads the temperature of Output FETS.                    | Y         | Read Only            | 2-bytes   |
| 90h     | Read_Fan_Speed_1   | Used to retrieve a two bytes value in Little Endian format representing the fan_1 speed of the device in a linear format (Fan_Speed_1 = Y*2 <sup>5</sup> ), where n is the exponent in two's compliment format, represented by the five most significant bits of the upper byte. Y is the mantissa represented by the eleven lower bits of the two byte word.  | Y         | Read Only            | 2-bytes   |

Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc

BPA-RS600-120-Preliminary 07-19-2018

Page 14 of 19


## 8. PMBus<sup>™</sup> Monitoring

| Param               | neter              | Description/Condition   | Min  | Nom | Max  | Units |
|---------------------|--------------------|---|------|-----|------|-------|
| V <sub>i mon</sub>  | Input RMS Voltage  | $V_{i \min} \le V_i \le V_{i \max}$                             | -3.5 |     | 3.5  | %     |
| I <sub>i mon</sub>  | Input RMS Current  |   | -2   |     | 2    | %     |
| P <sub>i mon</sub>  | Input Power        |   | -4   |     | 4    | %     |
| V <sub>1 mon</sub>  | V1 Voltage         |   | -0.5 |     | 0.5  | %     |
| I <sub>1 mon</sub>  | V1 Current         |   | -2   |     | -2   | %     |
| P <sub>o nom</sub>  | Total Output Power |   | -1.5 |     | -1.5 | %     |
| V <sub>SB mon</sub> | Standby Voltage    |   | -2   |     | 2    | %     |
| I <sub>SB mon</sub> | Standby Current    | I <sub>STBY</sub> >1A increase the percent error of the reading | -15  |     | 15   | %     |
| t <sub>1</sub>      | Temperature1       | Input Connector   | -2   |     | 2    | °C    |
| t <sub>2</sub>      | Temperature2       | Output Connector  | -2   |     | 2    | °C    |
| t <sub>3</sub>      | Temperature3       | Primary Section   | -2   |     | 2    | °C    |
| t <sub>4</sub>      | Temperature4       | Secondary Section   | -2   |     | 2    | °C    |
| Fs                  | Fan Speed          | Measurement Accuracy  | -5   |     | 5    | %     |
|                     | Fan Speed          | Control Range(0-23000RPM)                                       | 0    |     | 100  | %     |

## 9. Temperature and Fan Control

| Fan Speed   | RPM       |
|---|-----------|
| Nominal Fan Speed (Fan will start to speed up when the internal power supply module temperature exceeds 50°C)                     | 8000 RPM  |
| Maximum Fan Speed (Fan will reach its maximum speed of 23000 RPM when the internal power supply module temperature reaches 80°C.) | 23000 RPM |
| Minimum Warning Fan Speed   | 2500 RPM  |

**9.1 Fan Airflow** To achieve the best cooling results, sufficient airflow through the supply must be maintained. Do not block or obstruct the airflow on either side of the power supply.



Normal (Rear Exhaust) and reverse (Front Exhaust) airflow options are available. See ordering Information for details.

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power, Inc

Page 15 of 19

## 10. Connection

#### **10.1 Connectors**

Input ----- IEC320

Output ----- FCI P/N 10127397-23H1400



| P1      | P2      | P3      | P4      | 1       | 2  | 3      | 4     | 5     | 6     |   |
|---------|---------|---------|---------|---------|----|--------|-------|-------|-------|---|
|         |         |         |         | 12VS(+) | NU | 12VSB  | COM   | A2    | A1    | T |
| VO1_PWR | VO1_PWR | VO1_RTN | VO1_RTN | 12VS(-) | NU | PS_PRE | DC_OK | AC_OK | Alert | S |
|         |         |         |         | 12VCS   | NU | PS_ON  | SDA_1 | A0    | SCL_1 | R |

Note: 1T, 1R, 3S and 3R are short pins

| Pins    | Pin Type                    | Assignment | Description/Function  |
|---------|-----------------------------|------------|---|
| Output  |                             |            |   |
| P1, P2  | Power                       | VO1_PWR    | These are the +12 voltage output pins.  |
| P3, P4  | Power                       | VO1_RTN    | These are the 12V return output pins.   |
| Control |                             |            |   |
| 1T      | Signal                      | 12VS(+)    | (+) Sense - If remote sense is required this pin must be connected to the +12V load on the system backplane. This pin can be left open if remote sense is not required.   |
| 1S      | Signal                      | 12VS(-)    | (-) Sense - If remote sense is required this pin must be connected to the 12V return on the system backplane. This pin can be left open if remote sense is not required.  |
| 1R      | Signal                      | 12VCS      | Current Share - This pin must be connected to the 12V current share of the redundant power supplies on the system backplane. This pin can be left open if current share is not required.  |
| 3Т      | Signal<br>House<br>Keeping  | 12VSB      | 12V Stand by - This is the 12V standby output voltage pin.  |
| 3S      | Signal                      | PS_PRE     | Power Supply Present - This signal is connected to the common internally. This signal is used to identify that the power supply module is fully plugged into the system backplane   |
| 3R      | Signal                      | PS_ON      | Power Supply On - This is the power supply module control pin. This pin must be directly connected to common or controlled by a transistor connected to common on the system backplane.   |
| 4T      | Signal                      | COM        | Common - This is the common return pin for the power supply module.   |
| 4S      | Signal<br>Open<br>Collector | DC_OK      | DC Okay - This pin is used to monitor the output voltage. The signal on this pin will go high 100 to 150mSecs after the 12V output has reached regulation (above 11.5V). This signal will go low when the output voltage drops out of regulation (10.8V-11.5V). This pin must be connected to an external voltage via pull up resistor on the system backplane 20V max 10mA max.                      |
| 6S      | Signal<br>Open<br>Collector | ALERT      | Fault/Warning - An open collector signal is provided to indicate any fault or warning such as over temperature, overvoltage, over current, undervoltage, and fan fault.   |
| 5S      | Signal<br>Open<br>Collector | AC_OK      | AC Okay - This pin is used to monitor the AC input voltage. The signal on this pin will go high when the AC input voltage is above 88VAC. When the AC input voltage drops below 88VAC this signal will go low a minimum of 10mSec before the output voltage drops out of regulation. This pin must be connected to an external voltage via pull up resistor on the system backplane 20V max 10mA max. |
| 4R      | Signal                      | SDA_1      | Communication Data pin internal pulled up by a 3k $\Omega$ resistor.  |
| 6R      | Signal                      | SCL_1      | Communication Clock pin internal pulled up by a 3k $\Omega$ resistor.   |
| 5R      | Signal                      | A0         | Address Pin-This pin operates at 3.3V internal pulled up by a 10k $\Omega$ resistor.  |
| 6T      | Signal                      | A1         | Address Pin-This pin operates at 3.3V internal pulled up by a 10k $\Omega$ resistor.  |
| 5T      | Signal                      | A2         | Address Pin-This pin operates at 3.3V internal pulled up by a 10k $\Omega$ resistor.  |

Phone: 973-594-1800 Salesteam@BluTekPower.com


BPA-RS600-120-Preliminary 07-19-2018

© 2017 BluTek Power, Inc


Page 16 of 19

### 10.2 Parallel Wiring Diagram

Dash lines show remote sense connections.



### 10.3 Series Wiring Diagram (Requires Isolation on Main Output)\*



When operating in series the current share pin must be left open.

\*Look at Ordering Information on last page.

Phone: 973-594-1800
Salesteam@BluTekPower.com
© 2017 BluTek Power, Inc


BPA-RS600-120-Preliminary 07-19-2018

Page 17 of 19

## 11. Mechanical


| Parameter | Description/Condition | Min | Nom        | Max | Units   |
|-----------|-----------------------|-----|------------|-----|---------|
|           | Width                 |     | 50.5(1.99) |     |         |
| Dimension | Height                |     | 40.2(1.58) |     | mm(in)  |
|           | Depth                 |     | 245(9.65)  |     |         |
| Weight    |                       |     | 0.7(1.5)   |     | Kg(lbs) |

#### **Mechanical 3D Model Available**



## 12. Ordering Information

### Model number matrix for BPA-RS600-XXX-YY



**Technical Revisions** – The appearance of products, including safety agency certification pictured on labels, may change depending on the date manufactured. Specifications are subject to change without notice.

### **Custom Modifications and Voltages are Available**

#### MODEL No. / OUTPUT VOLTAGE / CURRENT RATINGS CHART

| Model No.     | O/P Voltage (Vdc) | Minimum | Maximum |
|---------------|-------------------|---------|---------|
| BPA-RS600-120 | 12V               | 0A      | 50A     |
|               | 12VSB             | 0A      | 1.5A    |
| BPA-RS600-240 | 24V               | 0A      | 25A     |
|               | 12VSB             | 0A      | 1.5A    |
| BPA-RS600-480 | 48V               | 0A      | 12.5A   |
|               | 12VSB             | 0A      | 1.5A    |
| BPA-RS600-560 | 56V               | 0A      | 10.7A   |
|               | 12VSB             | 0A      | 1.5A    |

### Contact Info:

Address: 300-1 Route 17 South Suite B2 Lodi, NJ 07644 USA

Phone: 973-594-1800

Email: Salesteam@BluTekPower.com

For more information on these products please contact a BluTek Sale Representative.

Phone: 973-594-1800 Salesteam@BluTekPower.com

© 2017 BluTek Power, Inc

中国区总代理:上海佳舍珀电子科技有限公司