## **Precision Vacuum Pressure Regulator 70 I/min**

Diaphragm vacuum regulator ensuring high precision in both vacuum and positive pressure range. Description

Media compressed air or non-corrosive gases

Supply pressure max. 17 bar

Accuracy response sensitivity: < 2 mbar by handwheel with locknut Adjustment

Air consumption max. 2.8 l/min in positive pressure range

Flow rate 70 l/min\*1 in vacuum range, 900 l/min\*2 in positive pressure range

G¼ on both sides of the body, screw plugs supplied Gauge port

Mounting position

-40 °C to 90 °C / -40 °F to 194 °F Temperature range

Material Body aluminium die-cast Inner valve: stainless steel and brass

Elastomer: NBR/Buna-N

G¹/₄ vacuum0.14/10 bar	

A B C D value rate thread range number mm mm mm m³/h m³/h*1 l/min*1 G bar		Dimensions			K <sub>v</sub> Flow		W	Connection	Vacuum	Order	
mm mm mm m³/h m³/h*¹ l/min*¹ G bar	Α	В	С	D	value	rat	e	thread	range	number	
	mm	mm	mm	mm	m³/h	m <sup>3</sup> /h* <sup>1</sup>	I/min*1	G	bar		

Vac	cuum	reg	ulato	or		supply pressure with constant b		R260		
76	184	20	65	0.78	4	70/90 <b>*</b> 2	G1/4	-1 +0.14	R260-020	
								-1 +0.7	R260-02A	
								-1 +2.0	R260-02B	
								-1 +7.0	R260-02C	
								-1 +10	R260-02D	



**NPT** connection thread R260-0 . . N


tamper-proof cap made of aluminium, adjustment by screwdriver, total height 189 mm R260-0 . . T



R260

## Accessories, enclosed

Ø 63 mm, -1 ... 0 bar, G1/4 pressure gauge mounting bracket made of steel




bypass regulation vacuum tank to close supply pressure or atmosphere

Bypass regulation
Upstream installation is preferred when rapid
exhaust of a tank or system is required. That way the
vacuum pump acts directly upon the tank and is not


being throttled by the vacuum regulator.

\*1 for compressed air at -0.98 bar supply pressure and 0 bar outlet pressure \*2 for compressed air at 7 bar supply pressure and 1.4 bar outlet pressure BW00-33


MA6302-00



BW00-33



connection for downstream regulation



Downstream regulation
The regulator is located between the pump and the tank. The vacuum pump is energy-saving and it is easy to fill the tank to its optimal level with pressure or vacuum.



vacuum pump



